REP-REP-RAF0163-6312860 Replacing control unit for left xenon headlight, VIN: XXXXXXX

ISTA system version	4.02.22.18122	Data version	R4.02.22.18122	Programming data	-
VIN	xxxxxx	Vehicle	5'/F10/SEDAN/535i/N55/AUTO/US/LL/2014/12		
Int.lev.works	-	Int.lev. (cur.)	-	Int.lev.(tar.)	-
Mileage	0 km				

63 12 860

Replacing control unit for left xenon headlight



Warning!

Version with xenon lighting system: Danger to life due to high voltage! Disconnect all components from voltage supply before removal.

Work on the entire xenon lighting system (ignition device, control unit and bulb) may only be carried out by qualified personnel.

Comply with notes and notes on handling exterior lights.




Important!

Read and comply with <u>information on</u> <u>protection against electrostatic</u> <u>discharge</u>!



Necessary preliminary tasks:


• Remove <u>left headlight</u>



Release screws (1).

Tightening torque 63 12 5AZ.

Remove control unit for xenon headlight (2) from headlight (3).



Installation note:

When installing control unit for xenon headlight (1), make sure sealing cup (2) is correctly seated.